



## METRO SHOWER SPECIFICATIONS

### METRO SHOWER BASE / TRAY

- One-piece, 3mm thick, marine-grade, epoxy-coated aluminium.
- Fibreglass-reinforced tray underside. Fully supported
- Single-plane slope to drainage channel: 'Fall' 1:50 to rear, front, left-hand or right-hand integral channel-drain
- Standard waste outlet position: End of drainage channel. Optional positions
- CUSTOM SIZES and waste-outlet position optional
- Tiling membrane factory-applied to tray -- allows usage of cementitious tile adhesive
- STANDARD SIZES: 30 plus
- Glazing channels: Matte-aluminium finish standard;. Optional bright-polished finish. Factory-installed to inside of tray
- Platinum 25-Year Leakproof Guarantee

### ON-FLOOR TRAY

- Threshold height 60mm. Threshold width 50mm.
- 'Step-down' 15mm from top of the threshold into tray for optimum water containment
- Installation on timber or concrete floor.

### LEVEL-ENTRY TRAY (15mm step-down)

- Installation onto rebated timber or concrete floor

### WHEELCHAIR ACCESS TRAY (no step-down)

- Flush entry (no step-down) -- Installation onto rebated timber or concrete floor.

### CHANNEL-DRAIN W EASY-CLEAN TRAP or WASTE FITTING

- Integral channel-drain with 40mm dia. Easy-clean trap or Waste fitting only (P- Trap required)
- Custom positioning of waste-outlet available

### CHANNEL COVER / GRATE OPTIONS

- (A) Stainless-steel Slotted-top (B) Stainless-steel Solid-top (C) Tileable channel cover (D) Stainless-steel Wedge-Wire (optional)

### FRAMELESS GLASS ENCLOSURE

- Thickness: 10mm toughened-glass.
- Standard Height: 2000mm. (Optional height)
- NZ Safety Standard compliant to AS/NZS 2206:1996
- Full enclosure with swing or sliding door, or 'Walk-in' panel-only
- Hinges: Chrome-on-brass. Self-centring
- Handle: Polished Stainless-steel Round 'D'. (Optional handles)
- Tray glazing channel: Matte aluminium finish. Factory-applied
- Wall glazing channel: Matte aluminium finish. Optional bright finish.
- Wall glazing channels applied directly to waterproofed walls

### LIQUID APPLIED WALL MEMBRANES

- Supplied by tiler or waterproofing contractor.  
See 'Recommended Waterproofing Membranes'

### INSTALLATION

- Tray to be installed with polymer-modified tile adhesive.
- Tile to be installed with correct tile adhesives.  
See 'Recommended Waterproofing and Adhesives'
- Frameless-glass enclosure to be installed by an experienced frameless-glass installer