

## GLASS INSTALLATION ALCOVE SHOWER

**NOTE:** Ensure hinge notch sidelite is installed the correct way up, i.e. the top notch is 220mm from top edge of panel and bottom notch is 240mm from bottom edge of panel.

With plumb walls, glass sits 17mm into channel with 12mm gap to back of channel

Glass sidelite is to be plumbed and made level with top of glazing channel. In shower interior, a continuous bead of clear silicone is to be applied between sidelite and channel. Sidelite is to be pushed hard against channel and excess silicone removed. At the shower exterior, silicone is to be applied between sidelite and glazing channel and excess silicone removed. Repeat process for other sidelite. Ensure the installed sidelites provide a 3mm gap each side of the door once installed.

Clear silicone applied into each tray / wall channel butt-joint immediately prior to installation of each sidelite

Clear silicone to bottom of sidelites to seal-off end of channels

Brace  
Overpanel

Brace Clamp Brackets

Handle

### CAUTION:

Wall channels **must** be adhered with the supplied silicone directly to the wall waterproofing before the installation of tile.

### VERTICAL GLAZING CHANNELS

Glazing channel adhered to waterproofed wallboard with continuous bead of silicone applied along entire length of back side of channel. Continuous bead of silicone applied to each side of channel / wallboard junction

9 / 10mm Setting Blocks.

Add levelling / height adjustment blocks as required

