



## INSTALLATION OVERVIEW. ON CONCRETE FLOOR



**STEP 1**  
Connect easy-clean trap body to outlet pipe. Install other required plumbing.



**STEP 2**  
Adhere Stile tray to floor with approved tile adhesive. Allow 24 hours curing before walking on tray.



**STEP 3**  
Install Quik NICHE if being utilised. Cut wet-area wallboard to suit and affix to framing.



**STEP 4**  
Apply waterproofing membrane to shower walls, shower tray, and bathroom floor. Adhere wall glazing channels directly to waterproofed walls.



**STEP 5**  
Apply tile to shower tray and walls. Install plumbing fixtures to shower. Install frameless-glass enclosure.