



INSTALLATION OVERVIEW. PLYWOOD ON-FLOOR



STEP 1

Connect easy-clean trap body to outlet pipe. Install other required plumbing.



STEP 2

Adhere Stile tray to rebated floor with approved tile adhesive. Allow 24 hours curing before walking on tray.



STEP 3

Install Quik NICHE if being utilised. Cut wet-area wallboard to suit and affix to framing.



STEP 4

Apply waterproofing membrane to shower walls, shower tray, and bathroom floor. Apply wall glazing channels to waterproofed walls.



STEP 5

Install plumbing fixtures to shower. Install frameless-glass enclosure.