



INSTALLATION OVERVIEW. REBATED PLYWOOD FLOOR



STEP 1
Rebate plywood floor to such depth that installed tray finishes flush with tile underlay board or underfloor heating screed. Connect easy-clean trap to outlet pipe. Install other required plumbing.



STEP 2
Adhere Stile tray to rebated floor with approved tile adhesive. Allow 24 hours curing before walking on tray.



STEP 3
Install Quik NICHE if being utilised.
Cut wet-area wallboard to fit and affix to framing.



STEP 4
Apply waterproofing membrane to shower walls, shower tray, and bathroom floor.
Adhere wall glazing channels to waterproofed walls.



STEP 5
Install plumbing fixtures to shower.
Install frameless-glass enclosure.