



## TRAY INSTALLATION ADHESIVES

### Manufacturer / Supplier

Ardex NZ  
ASA Bostick NZ  
Cemix  
Construction Chemicals NZ  
Davco

### Adhesive

Ardex X77  
Conflex  
Ecofix / Duraflex  
Flexiset / Rubberflex  
Ceramaflex / Ultraflex

## LIQUID-APPLIED TRAY AND WALL MEMBRANES

Selected membrane to be applied to tray tiling membrane to act as a primer prior to application of tile

### Manufacturer / Supplier

Ardex NZ  
ASA Bostick (NZ)  
Construction Chemicals NZ  
Construction Technologies  
Davco  
Flexco NZ  
Mapei NZ  
Technokolla (Protective Surfaces)

### Cementitious Membrane

Superflex WPM 002  
DampFix 3  
Liquid Flash 2  
AquaBlok 2  
Dampfast  
Miracryl  
Mapelastic Smart  
Rasolastik

### Urethane / Acrylic Membrane

Superflex WPM 001  
DampFix 2, DampFix Gold  
Liquid Flash 1  
AquaBlok 1  
Dampflex  
Flexi-Seal  
Mapegum, Aquadefense  
Rasogum

## CEMENTITIOUS TILE ADHESIVES

Selected membrane above to be applied to tray tiling membrane to act as a primer prior to application of tile

### Manufacturer / Supplier

Ardex NZ  
ASA Bostick NZ  
Australian Tiling Adhesives  
Cemix  
Construction Chemicals NZ  
Construction Technologies  
Davco  
Flexco NZ  
Mapei NZ  
Technokolla / Protective Surfaces

### Tile Adhesives

Ardex X77, Optima, Abaflex  
Conflex, MegaFix  
Aus-Crete Premium Industrial  
Flexiset, Rubberflex  
Monoflex, Gripflex  
Prohesive Proflex  
Ultraflex  
Flexi Wall & Floor  
Kerabond and Isolastic  
Techno One, Techno Star

## SYNTHETIC TILE ADHESIVES

Tile installed directly to epoxy-coated tray. (i.e.-- no tiling membrane on tray)

### Manufacturer / Supplier

Mapei NZ  
Sika NZ

### Tile Adhesives

Keralastic, Kerapoxy  
Fosroc Florbond 406, Ceram Epoxy

**NOTE:** All products listed above are suggested as suitable for the application to an Impresa shower tray and wall linings when used in accordance with the respective manufacturer's specifications. Impresa Tile Shower Systems Ltd. does not imply nor provide any warranties for any products listed herein.

